

SECURINA X AUSO

surface. 2. PLACE CAN OPENER HORIZONTALLY ONTO THE CAN. Indicator should align with rim.

. Place the can on a flat horizontal



3. Turn knob clockwise while maintaining can opener horizontal. Knob will move towards the centre of the can



and will remain there. Always remember to stop turning once can opener has cut rim one complete circle. You will feel the resistance change. Never over-cut by more than 30 mm.





5. Do not pry the lid off with your fingers. Always use the lid lifter provided. Press button to engage lid lifter. Release button to drop lid.



If you continue to turn once the can is opened, this may create metal shavings. Dispose of can carefully.

IMPORTANT

- a) It is important not to turn the knob counterclockwise and release the can opener if the can opener has not cut the rim one complete circle yet. In case there is a need to suspend the can opening process, simply leave the entire set-up where it is and resume turning knob to continue as required.
- b) The can opener is designed to be used on conventional household cylindrical cans, with a diameter between 54 mm and 100 mm, weighing less than 1.5kg.
- c) Best for rim height between 2.6mm and 3.1mm.
- d) It is important to clean your can opener régularly. Use warm soapy water to clean.

SECURIMax Auto



Patented lid lifter (5) Pince brevetée (5)

Made in China for / Fabriqué en Chine pour



