



Chopper SwizzzProzzz



Instructions

Usage

1. Remove the cutting blades from the protective case.



2. Place the blades in the middle of the container.



3. Prepare the food by cutting into rough pieces and place in the container. Do not fill any higher than the white guide on the blade set. The container capacity is 0.9 l.



4. Place the lid on the container. Be sure to stabilize the lid to the container by aligning the hexagonal part from the blade set to the hole of the lid.



5. Make sure to place the unit on a firm and dry surface while operating. Place one hand on the lid and pull the handle with a firm movement with your other hand.



Recommended cuts:



5-6
for thick medium cut



7-12
for medium fine cut



13-20
for fine very fine cut



The container can be used in the microwave. However, not more than two minutes and should not exceed the power of 800 Watt.

Cleaning

Just wash the lid with a damp cloth. If any water should get into the mechanism there is a round tab underneath the lid to release the water. Unscrew with a coin and allow it to dry before reassembling. Except the lid, all parts are dishwasher.

Storage

Always use the protective case to store the blades.



Recycle symbol
Plastic (PET) and metal (Al) are 100% recycled.
*This is a registered trademark of Starfrut GmbH.
Contact: 01 800 81 81 81 or 01 800 81 81 81