

## DIGITAL KITCHEN SCALE



Remove the used batteries and install new ones. Make sure to respect the polarity.  
Close the battery case cover.

Press **(MODE)** button to switch the mode and unit.

- Place the scale on a solid and flat surface
- Press  button to turn on the scale.
- Wait until LCD shows "0" to start weighing. Press  button to convert to weight mode if needed.
- Load weighing object on scale. LCD will show the weight reading.

Diagram illustrating the steps to use the digital scale for liquid measurement:

- Press **ZERO** button to turn on the scale.
- Press **MODE** button to convert scale to water or milk mode.
- Place a bowl or container on the weighing platform.
- Press **ZERO** button to reset the LCD screen at "0".
- Pour liquid (water or milk) into the bowl or container. LCD screen indicates the volume of the liquid (water or milk).

• **Tare function**

When sum of all loaded items is 0 g, LCD will show "0 g".  
Icon "T" will show on the left side of LCD.  
When tare function is activated, weight of loaded items is reduced by tare amount.

Under this condition, when additional items are loaded, the total weight of loaded items is shown.

**1. Low battery power**  
Please replace batteries.

**2. Overload**  
Remove item to avoid damage.  
Maximum capacity for this scale is 11 lb /

1. Always use the scale on a hard flat surface.
2. Clean the scale with a slightly damp cloth.
3. Avoid contact with water. DO NOT immerse the scale in water.
4. All plastic parts should be cleaned immediately after contact with fat, spices, vinegar and strongly flavored/colored food. Avoid contact with acid citrus juices.
5. DO NOT use chemical or abrasive cleaning agents.
6. Not for commercial use.

 [facebook.com/starfrit](https://facebook.com/starfrit)

SUBSCRIBE TO THE NEWSLETTER TO LEARN MORE ABOUT OUR PROMOTIONS!