

Starfrit

DIGITAL KITCHEN SCALE



INSTRUCTIONS FOR USE

SPECIFICATIONS

- Can be used with or without bowl
- Stainless steel weighing platform and bowl
- Also measures volume of milk and water
- Unit conversion feature
 - Weight: grams, pounds and ounces
 - Volume: milliliter and fluid ounces
- Automatic conversion feature imperial / metric
- Zero and tare functions
- Low battery and overload indicators
- Auto-off after two minutes or manual-off
- Scale capacity: 11 lb / 5 kg
- Bowl capacity: 47 oz / 1.4 L
- Accuracy: 0.1 oz / 1 g

BATTERIES

- Requires 3 AAA batteries (included).
- Remove isolation sheet before use.

TO REPLACE BATTERIES

- Open battery case cover underneath the scale.
- Take out the used batteries and install new ones. Make sure to respect the polarity.
- Close battery case cover.

LED SCREEN



- Weight mode
- Water mode
- Milk mode
- Zero function
- Negative value
- Tare function
- Volume
- Weight
- Volume

BUTTONS

- Press the circle button to turn on the scale. Once available, button would be lighted up and flicker.
- Button in power "OFF" status**
Press circle button to turn on the scale.
- Button in power "ON" status**
Turn OFF / Zero and tare functions.
- Mode and unit conversion

WEIGHING MODE

- Place the scale on a solid and flat surface.
- Press button to turn on the scale.
- Wait until LED shows "0" to start weighing. Press button to convert to weight mode if needed.
- Load weighing object on scale. LED will show the weight reading.

VOLUME WEIGHING MODE

- Place the scale on a solid and flat surface.
- Press button to turn on the scale.
- Press button to convert the mode to water or milk volume mode when LED shows "0".
- Place a bowl or container on the weighing platform. LED screen indicates the weight of the bowl or container. Press button to reset the LED screen at "0".
- Pour liquid (water or milk) into the bowl or container. LED screen indicates the volume of the liquid (water or milk).

ZERO AND TARE FUNCTIONS

The zero and tare functions allow you to weigh items consecutively without having to remove the article already on the platform. For example, if you are using a bowl, these functions allow you to weigh the content of the bowl without counting the weight of the bowl. Press to use these functions.

- **Zero function**
When sum of all loads on scale is less than 7 oz (200 g), the LED will show "0 g" each time button is pressed. Icon "o" will show on left of LED, indicating zero function is activated. The maximum capacity of the scale will not be reduced by the stated weight if it is 7 oz (200 g) or less.
- **Tare function**
When sum of all loads on scale is over 7 oz (200 g), the LED will show "0 g" each time button is pressed. Icon "T" will show on left upper corner of LED, indicating tare function is activated. Maximum weight capacity is reduced by tare amount.

AUTO SHUT OFF & MANUALLY SHUT OFF

- Auto shut-off occurs if display shows "0" or shows the same weight reading for 2 minutes.
- To maximize batteries life, it is recommended to shut off manually the scale. Press button for 3 seconds and the scale will turn off.

LOW BATTERY & OVERLOAD INDICATORS

- 1. Low battery power**
Please replace batteries.
- 2. Overload**
Remove item to avoid damage. Maximum capacity for this scale is 11 lb / 5 kg.

ADVISE FOR USE & CARE

1. Always use the scale on a hard flat surface.
2. Clean the scale with a slightly damp cloth.
3. Avoid contact with water. DO NOT immerse the scale in water.
4. All plastic parts should be cleaned immediately after contact with fat, spices, vinegar and strongly flavored/colored food. Avoid contact with acid citrus juices.
5. DO NOT use chemical or abrasive cleaning agents.
6. Not for commercial use.

SUBSCRIBE TO THE NEWSLETTER TO LEARN MORE ABOUT OUR PROMOTIONS!

www.Starfrit.com

www.facebook.com/starfrit