Starfrit Pump'N'Slice


INSTRUCTIONS FOR USE

SETTINGS I ocking button Foldable feet

ASSEMBLY

WASH THE APPLIANCE BEFORE THE FIRST USE, PLEASE REFER TO THE CLEANING SECTION IN THIS BOOKLET.

. **Unfold the slicer's feet** (Photo A). Always make sure that both sides are completely open (Photo. B).




Install the slicer on a clean and level surface for added stability

- 2. Remove the storage lid by pulling up the locking button.
- 3. **Install the feeder** by placing its bottom edge (straight and serrated side) first and then locking it into place by snapping in the
- 4. Unlock the spring pump by pressing down on the handle while exerting a slight rotation (see illustration on the handle). The pump will deploy and the blades will move upwards.
- 5. **Place the container** under the appliance and insert the pusher inside the feeder. The Pump'n'Slice is now ready to use.







SETTINGS THE CONTROL SETTINGS ARE LOCATED ON THE BACK OF THE SLICER **DIAL:** Select thickness of the slices, ranging from 0.5 mm to 8 mm, by turning the dial clockwise.

SETTING TAB: To activate the Julienne blades, lift the tab 90° from its base Rotate the tab a full turn and snap it back on its base.

1. **ONE TAB ACTIVATED:** One row of Julienne blades is activated. Perfect for thicker cuts.


2. **TWO TABS ACTIVATED:** Two rows of Julienne blades are activated. Perfect for thinner cuts.



To make sure the blades are activated, just look over the controls settings located on the back of the slicer.



SETTINGS AND CUTS CHART



USAGE

- 1. Set the controls (dial and tabs) to the desired thickness and cut (see the Settings and Cuts Chart).
- 2. Insert food inside the feeder and press down with the
- 3. Press firmly on the spring pump while maintaining pressure on the food pusher. Repeat until you get the desired

RECOMMENDATION

For longer foods such as cucumbers, hold the end of the food and slice until the same length of the feeder. Once the food can entirely fits inside the feeder, you can finish the operation with the pusher. Always use the pusher when slicing food that fits in the feeder.

CLEANING

- Wash the appliance before the first use.
- It is important to always use the cleaning tool to remove food residue and parts stuck in the blades to avoid any contact with the blades.
- Remove the storage lid and feeder to expose the blades.
- All parts of the slicer are dishwasher safe. It is recommended to unlock the spring pump and to fold the feet and place in the top rack of the dishwasher



www. Starfrit.com



www.facebook.com/starfrit

SUBSCRIBE TO THE NEWSLETTER TO LEARN MORE ABOUT OUR PROMOTIONS

PRINTED IN CHINA FOR: ATLANTIC PROMOTIONS INC. LONGUEUIL (QUÉBEC) J4G 1V6
CUSTOMER SERVICE: 1-800-361-6232 / MTL AREA: (514) 871-1095